

FAILURE MODE FOR HVAC SYSTEM
Applicant: Van Ostrand, et al.; Attorney docket 60246-336; 10,884
EXPRESS MAIL NO. EV220476196US

1/2




FIG.1




FIG.2

FAILURE MODE FOR HVAC SYSTEM

Applicant: Van Ostrand, et al.; Attorney docket 60246-336; 10,884
EXPRESS MAIL NO. EV220476196US

2/2

DETECT THE FAILED STAGE(S).

- A) DIRECT COMMUNICATION OR NO COMMUNICATION WITH THE FAILED EQUIPMENT; AND/OR
- B) MONITORING OF THE CONTROLLED AREA TEMPERATURE.

REMOVE THE FAILED STAGE(S) FROM THE STAGING SEQUENCE USED BY THE CONTROLLER.

CHECK THE FAILED STAGE PERIODICALLY TO SEE IF IT HAS BECOME FUNCTIONAL AND RETURN IT TO USE IF IT HAS.

FIG.3




FIG.4




FIG.5